



Need Help?


Scan the QR code or go to displayit.com/flare-guide to watch an assembly video.



6 - Frame Perimeter Pieces
(See Diagram 1 for details)



4 - Flat Connecting Plates with Wing Nuts




4 - Corner Connecting Plates with Wing Nuts



4 - Extra Wing Nuts
(1/4-20 Thread Size)



1 - Horizontal Support Bar



8 - Double-Sided Curtain Lights




8 - Power Supplies (100 Watts)


32 - Light Mount Clips*



2 - 10 Foot Power Cords with 5 Quick-Connects



6 - Wire Management Clips




2 - Flare Base Feet

8 - Screws for Flare Feet
(1/4-20 Thread Size)



8 - Washer Wing Nuts for Flare Feet*
(1/4-20 Thread Size)



1 - Displayit Multi-Tool

1. Unpack the frame. Save all foam pieces for repacking later. Lay out the frame pieces as seen in Diagram 1. Frame perimeter pieces are labeled with stickers matching Diagram 1 to make this step easier. Take note where the velcro strips for the power supplies are located on Diagram 1. Assemble the frame on its back.







Diagram 1



2. Assemble frame sides using two flat connecting plates. Hand tighten wing nuts to secure.




3. Assemble perimeter of frame with four corner connecting plates.




Note: It's best to build the frame laying on its back.






4. Locate the break where the two 92" Side Corner frame pieces meet. Insert the Horizontal Support Bar in the center channel at this point.

5. Using the provided multi-tool, rotate the 5mm hex key clockwise to lock Horizontal Support Bar in place. Repeat on opposite side.



6. Attach the bottom of the curtain to the center channel of the frame using light clips (Diagram 2). To attach clips, hook each clip through the wire loop. Squeeze clip, insert into channel, and release. Suggested light clip locations are marked on the ruler. Carefully unroll the curtain light and clip the top clips into the top of the frame, keeping the wires straight.



7. Attach the power supplies to the frame via the velcro strips and connect the wires to the curtain lights.





Diagram 2



8a. Run two power cables as shown by the blue and green lines in Diagram 2.
8b. Run the main power cables through the wire pass-through and connect to the power supply. Plug the cables into an AC outlet to test the lights.

9. To help stop wire shadows on the graphic, use the provided snap-on wire management clips. The curtain light clips may also be used for wire management.





Diagram 3



10. Prop up the bottom of frame as shown in Diagram 3. Place the Base Foot against the corner of the bottom right of frame. Slide in two bottom screws and hand-tighten with wing nuts.

11. Slide in two side screws and hand-tighten with wing nuts.

Repeat steps 10-11 for second Base Foot.

Graphic Installation





Caution! Installing silicone-edged graphics is technique sensitive; Practice will shorten installation time.







Handle graphics with care with clean hands in a clean environment. Cloth or latex gloves recommended. Keep graphics away from sharp objects.

- Using at least two people, carefully stand the display up. Starting in top-left corner, turn and tuck graphic and silicone into the channel. (#1 on diagram) Use your fingertip (not fingernail) for installation.
Note: For large frames, a step ladder may be required for graphic installation.



- Work across the top, tacking the graphic into the channel every two to three feet. (#2 on diagram)
- Tuck top, right corner into channel. (#3 on diagram)
- Tuck remainder of top edge of graphic into top channel. (#4 on diagram)
- Inspect graphic for hard fold lines in the fabric. If desired, smooth them out using a fabric steamer.
- Tuck bottom two corners. (#6 on diagram)
- Tack middle of sides. (#7 on diagram)
- Working from top to bottom, tuck remaining silicone in on both sides. (#8 on diagram)
- Tack middle of bottom. (#9 on diagram)
- Tuck remaining bottom edge, working from outside to inside. (#10 on diagram)
- Repeat installation steps for fabric on back of frame.





12. Carefully stand the frame up, using the feet as a pivot.

This should only be done by four or more people.